

Installation Tip

Robbins Top Boot For NA/NB Miata

PART # 239-420

1. Place the boot cover in the sun for 45 minutes or so to let the material get warm. The material is stiff when it is new and will require a little stretching.
2. Snap the two Tenax fasteners at both sides at the inside of the quarters first.
3. Install the black poly web safety strap that is sewn under the Boot, around the top frame and fasten the snap to the stud at the end of the poly web. This is to prevent the Boot from lifting off the vehicle at high speeds.
4. Fasten the plastic into the body channel on the body at both sides behind the door jam.
5. Fasten the plastic into the body channel at the center of the boot onto the car.
6. Finish installing the plastic extrusion around both sides of the car into the body channel, fitting the boot.
7. Snap the durable fasteners across the inside ledge behind the seats.

Moss Motors, Ltd.

440 Rutherford Street, Goleta, California 93117
In the US & Canada Toll Free (800) 667-7872
LOCAL (805) 681-3400 FAX (805) 692-2510



Moss Europe Ltd.

Unit 16 Hampton Business Park Bolney Way
Feltham TW13 6DB, United Kingdom
In the UK: 020-8867-2020 FAX: 020-8867-2030