



900-040 Hardtop Caddy and Cover Assembly Instructions

440 Rutherford St. Goleta, CA 93117
1-800-667-7872 • FAX 805-692-2525 • www.MossMotors.com



1. Locate the 2 long cross bars with the hole in the center and fasten them together in the center with one of the 5/16" x 3/4" bolts, 2 washers and acorn nut. This is going to make the cross bracing for the back of the cart.
2. Stand the base frame pieces in their upright position and locate the bar with the foam in the center. Attach one end of the cross brace assembly from step one along with one end of the cross bar and fasten to the upper most (threaded) hole on the back of the frame with one of the 5/16" x 3/4" bolts and washer supplied. Now attach to the other base frame with the bolt and washer supplied.
3. Connect the other ends of the cross bracing to the holes on the back of the frame using the 5/16" x 1 3/8" bolts, washers, and nuts supplied.
4. Put all 4 castors into place but do not put the nuts on the top yet. Use the 2 remaining cross bars and run them from side to side on top of the frame over the studs coming up from the castors. Now put the nuts on and tighten all nuts.

Although every effort has been made to ensure the accuracy and clarity of this information, any suggestions that you may have that will improve the information (especially detailed installation notes and photos) are welcome. These instructions were developed and written by Moss Technical Support. If you have any questions or difficulties with your installation of this product, telephone 800-667-7872 between 7:00 a.m. and 4:00 p.m., Pacific Time for assistance.

Moss Motors, Ltd.
440 Rutherford Street, Goleta, California 93117
In the US & Canada Toll Free (800) 667-7872
LOCAL (805) 681-3400 FAX (805) 692-2510



Moss Europe Ltd.
Hampton Farm Industrial Estate
Hampton Road West, Hanworth Middlesex, TW13 6DB
In the UK: 020-8867-2020 FAX:- 020-8867-2030