

Rear Spoiler Installation Instructions

Moss Part # 900-965

Spoiler Kit Includes:

- Rear spoiler
- Pedestal gaskets x3
- 1/4" coarse thread, stainless steel sheet metal screws x3

Tools Required for Installation:

- Drill
- 1/8" Drill Bit
- 5/16" Drill Bit
- 3/4" Drill Bit (some applications)
- Panel Puller (some applications)
- Masking Tape
- 3/8" Ratchet or Nutdriver
- Silicone Based Caulk
- Measuring Tape
- 3x5 Index Cards x3, and a pencil

Steps For Installtion:

- 1) Using a panel puller, remove any trim panels from the underside of the decklid. It is recommended to cover or remove any carpeted trunk mats or other items in the trunk area to avoid damage.
- 2) Make 3 paper templates (3x5 index cards work well for this purpose) by out lining the shape of each pedestal, making sure to include a mark for the screw hole.
- 3) Place template on each pedestal and secure with masking tape.
- 4) Place spoiler on closed decklid and align to proper position. A measuring tape will ensure a proper fit.
- 5) Using masking tape, secure templates to decklid of vehicle. Remove the spoiler, leaving the templates secured to the decklid.
- 6) Using a 1/8" drill bit, drill through the hole mark in the template and into the decklid. Remove the templates from the vehicle. If the decklid contains a double panel drill through the inner panel also.
- 7) Using a 5/16" drill bit, drill through the 1/8" hole created in step 6.
- 8) If a double panel exists, use a 3/4" drill bit to drill through the inner panel. This allows the ratchet or nut driver to secure the screw tightly in place against the upper panel.
- 9) Place spoiler on decklid and using the supplied screws secure the spoiler to the vehicle.
- 10) Apply small amounts of silicone based caulk over the spoiler screws as this will help prevent leakage, rust, and loosening of screws.
- 11) Reinstall any panels, mats or other items removed earlier during step 1.

Paint Instructions:

- 1) Inspect spoiler for imperfections. If filling is required use catalyzed body filler.
- 2) If catalyzed body filler is used, be sure to prime over spot.
- 3) Sand spoiler with a 400 grit (or finer) wet sand paper until surface is smooth.
- 4) Apply basecoat/clearcoat finish of your choice.

Important-

Please inspect your spoiler for the proper fit before painting or mounting. Parts which have been sanded, painted, drilled or otherwise modified cannot be returned.



MOSS MOTORS, LTD.

P.O. Box 847 440 Rutherford Street Goleta, California 93117 (800)235-6954 FAX (805)692-2525

Instruction sheet #900-965 11/01