



Front Stiffener Bar: Installation Instructions

Tools needed: Two 9/16" wrenches.

1. This bar fits all Miatas before the 1994 model year, when Mazda added welded-on brackets and front and rear stiffener bars as standard equipment. This bar "closes the box" of the front subframe to create a more rigid assembly and better ride. Confirm that your kit contains:

- 1 straight bar.
- 2 nuts, 2 bolts, 2 lock washers, 2 flat washers.

2. Jack up your Miata and place on jack stands. Refer to your owner's manual for safe jacking procedures.

3. Install the bar as shown in the illustration below. The access slot is small, so hold the nut in place with small fingers or tape while you turn the bolt in order to get threaded.

