

Action Cam Bumper Mount



Parts Included:

- > 1x Action Cam Bumper Mount
- > 1x Tow Hook Stud
- > 1x GoPro Attachment
- > 1x M10 Bolt

***No actual camera is included with this kit.**

Tools Required:

- > Socket Wrench
- > ¾", 7/8", or 1" socket (depending on stud size)
- > 8mm Allen Wrench
- > Plastic Pry Tool

Procedure

1. Remove the tow hook cover

Using your fingers, or a plastic prying tool, remove the factory tow hook cover to expose the tow hook receiver.



2. Install the tow hook stud

Screw the tow hook stud into the tow hook receiver, and tighten snugly with a socket wrench.



3. Attach the camera attachment to the tow hook stud

Assemble GoPro moun onto the M10 bolt. Use the 8mm allen wrench to attach the mount to the tow hook stud. Your GoPro attaches via the same method any other GoPro accessory uses. Simply remove the thumb screw, slide your camera into the fork, and reinstall the thumb screw.

